

CPS — Wheel to Wheel Step Bars

24-4000	Silverado/Sierra 2500HD/3500 Crew Cab, Short Bed - 01-08	CHR
24-4010	Ford F250/350/450/550HD Superduty Crew Cab, Short Bed - 99-08	CHR
24-4020	Dodge Ram Quad Cab 1500 98-01; 2500/3500 98-02, Short Bed	CHR
24-4030	Silverado/Sierra 1500/2500LD 00-08; 2500HD/3500 01-08 Ext Cab, Short Bed	CHR
24-4040	Ford F150 Supercrew, Short Bed - 01-03	CHR
24-4050	Ford F250/350/450/550HD Superduty Super Cab, Short Bed - 99-08	CHR
24-4060	Ford F150/250LD (Heritage Edition) Ext Cab, Short Bed - 99-04	CHR
24-4080	Dodge Ram Quad Cab 1500 02-08; 2500/3500 03-08, Short Bed	CHR
24-4090	Toyota Tundra Extended Cab, Short Bed - 99-06	CHR
24-4100	Chevy/GMC C/K-Series Extended Cab, Short Bed - 88-98	CHR
24-4120	Ford F150 Super Cab (excl. Heritage), Short Bed - 04-08	CHR
24-4130	Ford F150 Supercrew, Short Bed - 04-08	CHR
24-4140	Toyota Tundra D-Cab, Short Bed - 04-06	CHR
24-4150	Chevy Silverado 1500 Crew Cab, Short Bed (LD) - 04-08	CHR
24-4170	Toyota Tundra 2007 D-Cab Standard Bed	CHR

